

## **INSTALLATION STEPS**

HITCH WEIGHT: 28 LBS.

INSTALL NOTES:

INSTALL TIME: 45 MINUTES

Drilling required, fishwiring hardware

1) Lift trunk lid and roll back carpeting to reveal trunk pan. Using a 1 1/2" hole saw, cut a hole in the location shown in the trunk pan figures above. Make sure hole is centered between the spot welds as shown.

DESIGNED FOR USE WITH

BALL MOUNT # 36063

- 2) After cutting one hole per side, fishwire a carriage bolt and block thru the drilled holes and down thru existing slots in the frame rails as shown above.
- 3) Lower exhaust to allow room for securing fasteners to carriage bolts.

1.2

- 4) Remove the bottom bolt from the bumper bracket and return to vehicle owner. One each side of vehicle.
- 5) Raise hitch into position, being careful not to push carriage bolts back into frame.
- 6) Insert the 5/16-18 screws into the holes in the bumper brackets and thru hitch side plates as shown. Position the hitch arms onto the carriage bolts and secure with fasteners as shown.
- 7) Torque all 1/2-13 hardware to 75 lb.-ft., Torque 5/16-18 hardware to 18 lb.-ft. Secure exhaust into position.

PERIODICALLY CHECK THIS RECEIVER HITCH TO INSURE THAT ALL FASTNERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. A teration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.