

CATALOG NUMBER..... **217220**

APPLICATION ..... Dodge/Plymouth Colt, all Hatchback,

Notchback (trunk lid) 1985 ONLY

Mitsubishi Mirage, Htchbk,

HITCH CAPACITY ..... 1000 pounds gross trailer weight 100 pounds maximum tongue load  
OR the maximum load specified by the vehicle manufacturer:  
WHICHEVER IS LESS.PLEASE NOTE: This product complies with safety specifications and requirements for connecting  
devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. This hitch mounts directly to car's frame rails two places each side at existing threaded holes. These holes are at rear most point on frame rails just forward of lower body trim panel under bumper
  - A. COLT Notchback (trunk lid): These holes are unused and hitch can be bolted directly to the frame rails.
  - B. COLT and MIRAGE Hatchback: Tie down brackets are bolted at these holes each side and must be removed for hitch installation.
2. Bolt hitch to car's frame using 10 x 40mm screws supplied with hitch. Use one flat and lock washer per screw.
3. Final tighten fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

## FASTENERS:

- ① (4) 10 x 1.25 x 40mm screw  
(4) 3/8" flat washer  
(4) 7/16" lock washer