

CATALOG NUMBER.....217277
 APPLICATIONPontiac Fiero except GT models,

HITCH CAPACITY1000 pounds gross trailer weight 100 pounds maximum tongue load
 OR the maximum load specified by the vehicle manufacturer;
 WHICHEVER IS LESS.

PLEASE NOTE: This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. Fishwire backing plate (#713) and carriage bolt into cars frame at existing slots, location ② in diagram. Use access hole at end of car's frame. Position the hitch on car over screws ② and install washers and nuts ② without fully tightening.
2. Center the hitch on car and position fore/aft for best fit. Note that holes ① fall on "step" area at rear of frame. With hitch secure to car use hitch as a template to drill holes ① in frame 9/16" diameter.
3. Fishwire backing plate (#798) and carriage bolt into these drilled holes and hitch using access holes at end of car's frame again. Location ①. Install remaining washers and nuts ①.
4. Final tighten all fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

FASTENERS:

① (2) 1/2 x 1 3/4" carriage bolt
 (2) 1/2" flat washer
 (2) 1/2" lock washer
 (2) 1/2" hex nut
 (2) backing plate (#798)

② (2) 1/2 x 1 3/4" carriage bolt
 (2) 1/2" flat washer
 (2) 1/2" lock washer
 (2) 1/2" hex nut
 (2) backing plate (#713)

