

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3500 LBS. TRAILER WEIGHT & 350 LBS. TONGUE WEIGHT.




*****DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.*****

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

**** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY****

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

Parts List				
ITEM	QTY	PART NUMBER	DESCRIPTION	
1	1	1/2"	FISHWIRE TOOL	
2	2	1/2-13	HANDLE NUT	
3	2	1/2-13 x 1 3/4	CARRIAGE BOLT	
4	2	HFN 1213	HEX FLANGE NUT	
5	2	CM-SP6	.250 x 1.00 x 3.00" SQUARE HOLE SPACER	
6	2	1/2"	LOCK WASHER	
7	2	1/2-13 x 1	HEX BOLT	



HITCH WEIGHT: 33 LBS.

INSTALL TIME

PROFESSIONAL: 30 MINUTES

NOVICE (DIY): 65 MINUTES

INSTALL NOTES:

- Drilling required
- Fishwiring required
- Lower exhaust for ease of installation

INSTALLATION STEPS

- 1) Raise hitch and position over existing bumper support bolts.
- 2) Place 1/2" x 1" hex bolt and lock washer in existing bumper support holes and secure with handle nuts.
- 3) Use the hitch as template to drill 1/2" holes in frame rails.
- 4) Fishwire spacer and bolt in through existing hole in frame rail and out previously drilled holes.
- 5) Attach flange nuts to each 1/2" bolt and properly torque all fasteners to 75 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.