

TRAILER HITCH MOUNTING INSTRUCTIONS

CATALOG NUMBER..... 247244

APPLICATION..... Volkswagen Jetta (except Wolfsburg edition),

HITCH CAPACITY..... 2000 pounds gross trailer weight 200 pounds maximum tongue load
OR the maximum load specified by the vehicle manufacturer;
WHICHEVER IS LESS.

PLEASE NOTE: A. This hitch features a removable ball mount. This hitch is not intended for use as a weight distributing hitch. Before towing, the hitch pin and retainer clip **MUST** be in place securing ball mount to receiver.
B. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York and regulation V.E.S.C. V-5.

1. Position the hitch against the car's trunk floor and bumper as shown, centered and square with the car. Check dimension "A" for enough ball/ bumper clearance. Remove any plastic material where hitch bracket contacts bumper. Hitch must fit directly to metal surface.
2. Use the hitch as a template to mark for mounting holes four places in floor; two places at bumper. Centerpunch these locations. Clear trunk for drilling and drill four places for 3/8" diameter screws. Drill bumper two places for 7/16" diameter screws.
3. Mount the hitch to car using fasteners ① and ②. Note that fender washers are placed **INSIDE** opposite the hitch. Use the spacer (#471) at Jetta's corrugated floor.
4. Final tighten all fasteners as specified on reverse of these instructions. Recheck all fasteners occasionally for tightness.

FASTENERS:

- ① (4) 3/8 x 1 1/4" screw
(4) 3/8" fender washer
(4) 3/8" lock washer
(4) 3/8" hex nut
(2) spacer (#471)

- ② (2) 7/16 x 1 1/2" screw
(2) 7/16" flat washer
(2) 7/16" lock washer
(2) 7/16" hex nut

