

**INSTALLATION INSTRUCTIONS****MODEL NO. 36500**

**WARNING:** Although this hitch is designed to safely tow its rated load, we recommend that you consult your vehicle owners manual for possible manufactures recommendations or limitations. Always follow the manufactures installation instructions and always install on the specified vehicle. Before installing hitch, check that the attachment points are in good condition.

Failure to follow these guide lines will void warranty. Any modifications to this hitch will void warranty.

**HITCH CAPACITY**

**3500 LBS. MAXIMUM TRAILER WEIGHT**  
**350 LBS. MAXIMUM TONGUE WEIGHT**


Trailer brakes are recommended for towing loads in excess of 1500 lbs.

**APPLICATION:** 1973-91 Chevrolet Suburban  
 1973-91 GMC Suburban


**PARTS INCLUDE:**

- |                                  |  |
|----------------------------------|--|
| 1. Hitch Assembly (1)            | 6. 1862-03 1/2-13 Hex Nut (2)          |
| 2. 1001-03 3/16 Spacer Plate (6) | 7. 1880-03 1/2 Lockwasher (4)          |
| 3. 1002-03 3/8 Spacer Plate (4)  | 8. 1837-03 1/2-13 x 1-3/4 Hex Bolt (4) |
| 4. 3119-03 1/2 HD Flatwasher (4) | 9. 1838-03 1/2-13 x 2 Hex Bolt (2)     |
| 5. 4442-03 1/2-13 Tab Nut (2)    |  |

**Vehicle Side Frame  
Without Spacer**



**Vehicle Side Frame  
With Spacer #3 In Place**



1. Position hitch assembly #1 against the bottom of the vehicle frame so that the ball platform section of the ball mount clears the license plate located in the bumper. Check for adequate coupler clearance. Drill two 1/2" attachment holes in each vehicle frame using the slots in the hitch frame brackets as guides.

2. Bolt hitch assembly in place as illustrated. **NOTE:** Some applications will require the use of spacer plates between the frame brackets and vehicle frame to level hitch. If rivets in vehicle frame prevent the hitch from resting flat on the frame, use the 3/8 spacers #3 to raise the hitch away from the rivets. Use the longer 1/2" bolts #9 for attachment when spacers are used.


3. On applications where the cross frame member blocks direct access to the forward hitch attachment points, insert the tab nuts #5 through the access hole in the cross member to secure the hitch. See Illustration 2.

4. Tighten all bolts to 75 ft. lbs. torque. Failure to tighten bolts as described may result in fastener loss or failure

**NOTE:** Ball mount is not supplied with this hitch. Use a 36071 or 36072 ball mount which must be purchased separately.

**WARNING:** Use only the ball mount supplied with this hitch. Use this hitch only as a weight carrying hitch. Do not use with any type of weight distributing hitch.

**WARNING:** Be sure to check hitch pin and hair pin for positive locking placement before towing trailer.



For information regarding this product, or our warranty, contact your dealer or write to "CUSTOMER SERVICE MANAGER" 1972 Brown Rd., Auburn Hills, MI 48326

**NOTE:** Some states require a clearview of license plate. Remove ball when not in use if it restricts view.

**NOTE:** This product complies with regulation V-5, C.S.A. Standard D-264 and safety requirements for connecting devices and towing systems of the State of New York.

**6574-52**